



**DESIGN SPECIFICATIONS** 

√High quality,reliable,long life and complete power unit. √ compact design.

√Easy start and maintenance possibility. √Every generating set is subject to a comprehensive test programme which includes full and testing and checking and proving of all control and safety shut down functions testing.

VW-258T6 powered by: TAD754GE

 $\sqrt{\text{Fully}}$  engineered with a wide range of options and accessories:Electrical,mechanical,soundproof canopy and mobile units

## Diesel Genset Features

Diesel Genset Features		P.I	F=0.8 3Phase
Service		P.R.P	Standby
Rated output	kVA	258.0	280.0
Active power output ※	kW	206	228
Rated Speed	r.p.m	18	300
Standard Voltage	V	380	/220
Voltage available	V	480/277-460/265 - 440/254-416	6/240-240/139-220/127-208/120

erforemance data refer to Standard Reference Conditions of ISO 8528:+25°C,100m ALT,relative humidity 30%

wer reduction acc.to DIN ISO 3046 Standard values:Above 100m ALT approx.1% per 100m.Above 25℃(77°F) approx.4% per 10℃(50°F). \*\*Considering cos phi=0.8

Prime Mover Performance		1800 r.p.m	
SERVICE		P.R.P	Standby
Rated output	KW	237	260
Manufacturer		VOLVO	PENTA
Model		TAD7	54GE
4 stroke Diesel Engine - Injection type		Di	rect
Aspiration type		Turbo	charge
Cylinders,number and arrangement			ô
Bore×Stroke	mm	108	X130
Total Displacement	L	7.	15
Cooling system		W	ater
Compression ratio		11	7:0
Specific fuel consumption(P.R.P)	L/H	61	.48
Total coolant capacity	L	3	34
Speed governor	Туре	Common rail with CA	N-bus communication

DP.R.P. Prime Power - ISO 8528:PRIME POWER is the maximum power available during a variable power sequence, which may be run for an unlimited number of hours per year, between stated maintenance ntervals. The permissible average power output during a 24 hours period shall not exceed 80% of the prime power. 10% overload available for governing purposes only.

②Max Standby power -ISO 3046 Fuel Stop power:Power available for use at variable loads for limited annual time (500h), within the following limits of maximum operating time: 100% load 25h per year ,90% load 20h per year. No overload available. Applicable in case of failure of the main in areas of reliable electrical network.

Synchronous Generator				
			Cuprinka	
Manufacturer			Guericke	
Model			GRK 206G4	
Rated output			206	
Poles	num		4	
Winding Conections (standard)			Star-serie	
Insulation	class		Н	
Enclosure(according to IEC-34-5)			IP23	
Phases			3+N	
Votage Regulaors			A.V.R (SX460)	
Steady voltage precision		within±1.5%	from no load to full loading with co	sΦ=0.8-1.0
%Alternator used by GTL Gensets meet the requirements of following Standard:BS500	00,VDE0530,NEMA M0	G1-32,IEC34,CA C22.2-100,AS1359		
Generationg Set Installation Data		1800 r.p.n	n	
EXHAUST SYSTEM		•		
Exhaust Gas Temperature at full load	°C		485	
	°F		905	
Exhaust gas flow Maximum allowed back pressure	L/s Kpa		661.7 7	
AIR REQUIREMENT	кра		1	
	L/s		231.7	
Air requirement for combustion at 100% load/rated speed	ft3/min(CFM)		490.6	
ELECTRIC STARTING SYSTEM	1			
Starting motor output	kw		5	
Standard Battery Charging System	A		100	
Auxiliary voltage	V		24	
LUBRICATION SYSTEM				
Lube oil system including sump,filters,etc.	L		34	
Standard Control Panel -EPmaster EPM6				
Protection, distribution, and automatic control panel, which starts the generator set whether the starts are set whether the starts are starts and starts are starts are starts and starts are starts		Faceplate	Controller	Internal Structure
failure and stops it when the mains is restored with the control unit EPM6. It also start	s and stops the group		EPMASTER	
manually via a pushbutton or remote start-up by contact.				
It has the following:				
<ol> <li>Emergency stop push button</li> </ol>				
(2) Protections:		🖌 🖌 🖉		And a state of the
Circuit breaker (preheating resist.) 2P (16 A)		PORTE DEPICE LARE DEPICE		
Protection fuses for control module		GCB	Emergency Stop Button	Optional: ATS
③ Voltage&speed trimmers		and the second		
Battery charger     BC mitch			0 0	
⑤ DC switch ⑥ Working Lamp switch			State NOY of	
<ul> <li>⑦ Distribution:Direct output of the circuit breaker</li> </ul>				
EPM6&EPM6+(cloud monitoring communication		Elere *	3 8	
4G)control and protection centre				

EPmaster EPM6			
It has a digital LCD screen, which provides easy reading of the i	nformation regarding the Engine Alterator Mains and Charging	The controller me	ets all requirements for Auto Mains Failure (AMF) applications
including remote communication and internet control, user config		The controller filler	
• READINGS that can be made:	•Protection of the engine and alternator, with the ALARMS activated:	•Other charac	teristics:
<u>Engine</u> :cooling temperature/oil pressure/revolution speed (rpm)/fuel level/battery voltage/battery alternator voltage/operati ng hours/number of start	Engine : low oil pressure/high coolant temperature/low and hi gh battery Voltage./failure of the alternator to charge batteries /Low fuel level.	(can be set as sta	e clock, scheduled start & stop generator rt genset once a day/week/month whether with load or not). Maximu an be memorized.
Alterator : voltages between phases and between phases and neutral/frequency/phase sequence	Alterator: Jow and high voltage/low and high frequency/overl oad /short-circuit/		function. Types (date or running time) can be optional and actions ( shutdown) can be set when maintenance time out.
<u>Mains:</u> frequency/voltages between phases and between phas es and neutral (L1-N, L2-N,L3-N)/voltages between phases and (L1-L2, L2-L3, L1-L3)/phase sequence	Mains; over and under voltage and loss of phase	monitor frequently temperature, oil p	NBUS port and can communicate with J1939 enginet. Not only can -used data (such as water ressure, speed, fuel consumption and so on) of ECU machine, but al up, shutdown, raising speed and speed droop via CANBUS port
	•Control of the set:		ation interface enables "Three remote" functions emote measuring and remote communication) according to MODBU
	STARTS and STOPS the set AUTOMATICALLY when mains failure is detected and when it is restored, respectively.It can also operate MANUALLY and Auto Transfer Switch control	Parameter setting and cannot be los	: parameters can be modified and stored in internal FLASH memory t even in case of power outage; most of them can be adjusted using f pontroller and also can be modified using PC via USB or RS485 port.
Standard Configuration & Option			
• •			
Item	Standard		Option
	Standard air filter		Heavy duty air filter
	Standard fuel filter		Air intake shutoff valve chalwin type
	Standard oil filter		Intake air heater
	Low coolant level sensor		Oil temperature sensor
	Exhaust gases compensator		Diesel-powered heater
Faraina.	24V Electrical system		Engine water heater
Engine	Radiator with bloweing fan		
	Electronic governor		
	Sender WT		
	Sender OP		
	Hot components and radiator guards		
	Mobile components guards		
	Self-excited and Self-regulated		Air inlet filter
	IP23 protection degree		IP44/IP54/IP55
	Insulation H class		Space heater/anti-condensation heater
Alternator			Environment protection
			Temperature detectors
			Parallel operation
	Battery isolator switch		Distribution board with sockets kit and power busbar
	3 poles circuit breaker		4 poles circuit breaker
Electrical system	Door opening alarm		Adjustable ELCB (Earth Fault )
	Battery charger 220-240V		Grouding rod
	Dattory onlargor 220-2401		ATS
	Water separator filter		Diverter valve kit for external fuel tank
	Low fuel level alarm		Automatic fuel refilling kit
Accessories	Oil extraction pump		Trailer
10000001100	Tool kit for maintenance		Residential silencer
	Voltage/Speed potentiometer		Electric engine fuel heater
	No Expansion tank		Expansion tank for coolant water
	No Expansion tank		Expansion tank for coolant water

Over All Size Length Height

Shipping Volume

Dry Weight Fuel Tank Capacity

Width


## Generating Set transport data

Dimensions(Open Skid Type) With Standard Fuel Tank



VThe complete gen-set is mounted on whole on a heavy-duty fabricated,steel base frame. √ Antivibration pads are fixed between the engine/ alternator feet and the base frame ; √ Base frame design incorporates an integral fuel tank. √ The generating set can be lifted or carefully pushed / pulled by the base frame; Ubial type fuel gauge and drain plug on the fuel tank; √ Forklift pockets within base frame (up to 500kVA);

## Dimensions(Silent Type) With Standard Fuel Tank



Over All Size		
Length	mm	4360
Height	mm	1700
Width	mm	2300
Shipping Volume	m3	17.05
Dry Weight	Kg	4331
Fuel Tank Capacity	L	500

mm mm

mm

m3

Kg

vali canopy parts are designed with modular principles. √ Without welding assembly √ All metal canopy parts are painted by electrostatic polyester powder paint. √Doors on each side √Thermally insulated engine exhaust system. √Emergency stop push button outside of canopy. √Easy maintenance and operation.



Tongan Industry Zone, Tongan District, Xiamen, China | Tel: +86 0592 7196398 | Fax: +86 0592 7898663| E-mail: vicsun@cngtl.com |www.cngtl.com



3300 1390

1830

8.39

2971 500